



## REPAIR CAPABILITIES

### F-16 REPAIR CAPABILITIES

<u>PART NUMBER</u>	<u>NSN</u>	<u>DESCRIPTION</u>	<u>APPLICATION</u>
10-01109-06	5998-01-187-3272WF	Electronic Tray Ass'y	F16
10-01109-07	5998-01-187-3272WF	Electronic Tray Ass'y	F16
10-01125-05	5895-01-143-5443WF	Data Entry Display	F16
10-01125-06	5895-01-143-5443WF	Data Entry Display	F16
10-01125-08	5895-01-143-5443WF	Data Entry Display	F16
10-01126-6	6130-01-207-2734WF	Power Supply	F16
10-01126-7	6130-01-207-2914WF	Power Supply	F16
10-01128-06	5895-01-181-1224WF	Display Head Ass'y	F16
12604334-1, -2, -3, -4	6625-01-124-0226-WF	Frequency Multiplier	F-16 - APG-68
12607539	6625-01-126-0097WF	Frequency Synthesizer	F 16 - APG-68
12609185	1280-01-126-0079WF	Radar Set Sub Ass'y	F-16
12609799	6625-01-126-0097WF	Frequency Synthesizer	F 16 - APG-68
1419000G4	6130-01-343-1930WF	Power Supply	F-16 - HUD
226891-001	5998-00-477-5944EW	CCA (Mixer)	F-16
4000060999	5821-01-067-1767	Control Box	F-16
5091200-003, -004	6340-01-153-8696WF	Eng Warning Cntrl Alarm	F-16
5091200-014, -018	6340-01-507-1788WF	Eng Warning Cntrl Alarm	F-16
5091200-007, -012	6340-01-317-7207WF	Eng Warning Cntrl Alarm	F-16
5091200-016, -020	6340-01-507-1824WF	Eng Warning Cntrl Alarm	F-16
580R276H01	1430-00-018-8535	Oscillator	F-16 - APG-66
580R414H02	1430-00-833-9603	Frequency Multiplier	F-16 - APG-66
583R290H01	1270-01-077-0718WF	Beacon, Low	F-16 - APG-66
583R292H01	1270-01-077-0714WF	LO VCO	F-16 - APG-66
583R936H01, -02	1270-01-096-7120WF	Frequency Multiplier	F-16 - APG-66
583R936H03	1270-01-222-3541WF	Frequency Multiplier	F-16 - APG-66
583R936H04	1270-01-096-7120WF	Frequency Multiplier	F-16 - APG-66
583R936H05	1270-01-343-8506WF	Frequency Multiplier	F-16 - APG-66
586R212H06	5841-01-353-9263WF	Microwave Transmitter	F 16 - APG-68
586R212H05	5841-01-291-6174WF	Microwave Transmitter	F 16 - APG-68
586R212H03	5841-01-203-4624WF	Microwave Transmitter	F 16 - APG-68
586R212H07	5841-01-438-9423WF	Microwave Transmitter	F 16 - APG-68
587R226H01	5865-01-253-5017	VCO, Band 3	F-16 - APG-66
588R881H01	1280-01-439-0638WF	Power Supply - Recei	F-16



## F-16 REPAIR CAPABILITIES (Continued)

<u>PART NUMBER</u>	<u>NSN</u>	<u>DESCRIPTION</u>	<u>APPLICATION</u>
612R653G02	1430-00-934-1086	Pre-Amplifier	F-16 - APG-66
681R112G01	6130-01-077-0836WF	Power Supply	F-16
681R267G01	1270-01-080-1216WF	DSP Power Supply	F-16 - APG-66
681R290G01	1270-01-077-8077WF	AZ-EL Computer	F-16 - APG-66
681R621G01	5998-01-099-3253WF	Electronic Component Ass'y	F-16 - APG-66
682R717G01	5998-01-101-5290WF	Circuit Card Ass'y	F-16 - APG-66
682R727G01	1270-01-099-3206WF	Low Noise Ass'y	F-16 - APG-66
682R732G01	1270-01-099-3205WF	Phase Lock Loop	F-16 - APG-66
688R012G01	5998-01-107-0140WF	Circuit Card Ass'y	F-16 - APG-66
690R935G01	1270-01-194-5732WF	Receiver Ass'y	F-16
691R748G01	1270-01-132-6867WF	Low Noise Ass'y	F-16 - APG-66
708985-6	6130-01-144-9322WF	Power Supply	F-16 - HUD
7506-00089	6130-01-181-4397WF	HUD Power Supply	F-16
7506-00091	6130-01-185-7755WF	HUD Power Supply	F-16
7506-00091	6130-01-185-7755WF	LV Power Supply	F-16
7506-00097	1270-99-735-6318WF	HUD Power Supply	F-16
7506-00098	6130-99-741-9556WF	HUD Power Supply	F-16
7506-00098	6130-99-741-9556WF	LV Power Supply	F-16
7506-00104	6130-99-776-6884WF	HUD Power Supply	F-16
708985-6	6130-01-144-9322WF	Power Supply	F-16 - HUD
750R821G01	1270-01-168-5002WF	Frequency Synthesizer	F-16 - APG-68
750R824G01	1270-01-168-5004WF	Frequency Oscillator	F-16 - APG-68
758R570G01	1270-01-208-8409WF	Reference Oscillator	F-16
758R758G01	1270-01-195-7397WF	AZ-EL Computer	F-16 - APG-68
765R005G01	6130-01-257-2835WF	DSP Power Supply	F-16 - APG-68
765R581G01	5998-01-280-8685WF	Circuit Card Ass'y	F-16 - APG-66
782R650G01	1280-01-126-0079WF	Radar Set Sub Ass'y	F-16